

# Mute Control Group

There are 6 buttons which allow you to mute various pre-configured channels, eb, all instruments, all mics, etc.

Step	Description	Notes
1	Select the "Mute Group" button on the display area (Area D)	
2	Press and hold a Mute Group button, and then select the channel to mute by pressing the relevant "Select" buttons	
3	Repeat for other Mute Group buttons	
4	Deselect the "Mute Group" button on the display area (Area D)	

From:  
<https://x32-desk.toft.org.uk/> - **Behringer X32 Manual**

Permanent link:  
<https://x32-desk.toft.org.uk/doku.php?id=mutegroup>

Last update: **2026/04/23 18:58**

